

NEON MICRO ARC | HORIZONTAL BENDING | ELECTRICAL AND PHYSICAL INSTALLATION GUIDE

ELECTRICAL & OPTICAL DATA VARIANCE +/- 10% SOLD BY THE METRE

CODE

BL-LS-4850-30-HB

BL-LS-4850-40-HB

BL-LS-4850-57-HB

IES FILES AVAILABLE

COLOUR

WARM WHITE


3000 К _{+/-} 175 к NATURAL WHITE

4000 К +/- 275 к COOL WHITE


5700 К +/- 300 К









BENDING PARAMETERS



Avoid bending LED Neon within the first unit (units are clearly marked with dashed lines on the sides of the preduct)
LED Neon can be bent up to the defined "minimum bend radius" (50mm for Neon Micro Arc)






info@lightculture.com.au | <u>www.lightculture.com.au</u>

Actual product characteristics may vary. Light Culture Australia Pty Ltd reserves the right to improve, modify or update the product designs without prior notice.



NEON MICRO ARC | HORIZONTAL BENDING | ELECTRICAL AND PHYSICAL INSTALLATION GUIDE




- LED Neon must always be used in conjunction with a certified Bright Light 24V DC power supply.

WIRING DIAGRAM


- Check the polarity of the connector before inserting the front connector and switching on the mains power.
- To minimise voltage drop and ensure consistent light output, position the power supply near to the power feed end of the LED Neon, and keep the line as short as possible.
- Ensure to add 20% buffer when selecting a power supply.
- Ensure your maximum run per power feed adheres to the guidelines; 10m when using a single connector, or 20m when using both connectors (see specification sheet).
- Before making any cuts, installation, maintenance, or connection, be sure the mains power is disconnected.
- If essential; cut and connect LED Neon correctly. Any incorrect operation can cause damage.
- All connector joints must be connected correctly to achieve connector IP rating.

PROFILE INSTALLATION REQUIREMENTS

- Ensure the supply cord is not subject to mechanical stress
- Keep 10-20mm distance between the end of the profile and the end mounting piece



- The bend angle should be less than 15 degrees when installing LED Neon into the profile by hand



Actual product characteristics may vary. Light Culture Australia Pty Ltd reserves the right to improve, modify or update the product designs without prior notice



NEON MICRO ARC | HORIZONTAL BENDING | ELECTRICAL AND PHYSICAL INSTALLATION GUIDE


PROFILE INSTALLATION REQUIREMENTS

X

- Avoid placing mechanical stress on the front connector cable
 - Do not curl or bend the front connector cable with excessive force



- Avoid installing the profile less than 10mm from the end mounting piece



- Install the LED Neon into the profile in one direction, don't let it bow in the middle



Actual product characteristics may vary. Light Culture Australia Pty Ltd reserves the right to improve, modify or update the product designs without prior notice.



NEON MICRO ARC | CONNECTIONS

SWIVEL CONNECTIONS - IP20

FEED CONNECTOR SUPPLIED AS 1M CABLE DOUBLE POWER FEED: FEED 01 + FEED 02





TOP END FEED

02

BL-LS-4852


END CAP


BL-LS-4854


01

BL-LS-4851

WHITE - VERTICAL & HORIZONTAL BENDING








END CAP

SLIMLINE INJECTION MOULDING CONNECTIONS - IP67


REQUIRES FITTING AT FACTORY. LEAD TIMES APPLY FEED CONNECTORS SUPPLIED AS 1M CABLE STANDARD, CHECK FOR ALTERNATE LENGTHS




WHITE - VERTICAL & HORIZONTAL BENDING













BOTTOM END




info@lightculture.com.au | <u>www.lightculture.com.au</u>



NEON MICRO ARC | MOUNTING ACCESSORIES







info@lightculture.com.au | <u>www.lightculture.com.au</u>

Actual product characteristics may vary. Light Culture Australia Pty Ltd reserves the right to improve, modify or update the product designs without prior notice.