
## INSTALLATION INSTRUCTIONS HELIUM MAJOR





## INSTALLATION INSTRUCTIONS


1.



2.










3



4.



## SAFETY NOTES

- INSTALLATION BY SUITABLE TRAINED AND QUALIFED PERSONAL ONLY.
- NEVER WORK WHEN VOLTAGE IS PRESENT ON THE FIXTURE
- IN THE CASE OF MALFUNCTIONS WITH THE FIXTURE PLEASE CONTACT LIGHT CULTURE
- LED MODULE RISK GROUP ONE



WARNING - RISK OF ELECTRIC SHOCK

 THE MAXIMUM PERMISSABLE AMBIENT TEMPERATURE Ta OF THE LUMINARE MAY NOT BE EXCEEDED. EXCEEDING THIS TEMPERATURE REDUCES THE SERVICE LIFE AND, IN EXTREME CASES, EARLY FAILURE CAN OCCUR.







